


SR3 RS 24V Starting



Ref	Part No	Description	Qty
1	LB0001	Battery	2
2	LB0003-G3	Battery Cover Medium	2
3	LB0013	Battery Retaining Strap	2
4	LB0020	Battery Tray	1
5	LB0027	Battery Tray	1
6	LB0067	24V Charging Module	1
7	LH0161	Charging Loom	1
8	LH0165	Starter Solenoid to Slave Lead	1
9	LH0166	Slave Battery to Motor Lead	1
10	LS0039	Switch Insulating Boot Small	2