


SR3 RS Battery and Wiring Assembly (1340)



Ref	Part No	Description	Qty
1	LH0139	Chassis Wiring Harness	1
2	LH0094	Chassis Engine Loom	1
3	LH0095	Alternator Control Loom	1
4	LH0013	Battery to Master Switch Lead	1
5	LH0015	Battery Chassis	1
6	LH0057	Master Switch to Starter Solenoid	1
7	LH0076	Starter Solenoid to Starter Motor	1
8	LH0089	Battery Starting Cable Long	1
9	LH0017	Battery Starting Cable Short	1
10	LS0038	Switch Insulating Boot Large	2
11	LS0039	Switch Insulating Boot Small	3
12	LB0010	Battery 12V	1
13	LB0020	Battery Tray	1
14	LB0016	Battery Jump Lead bracket	1
15	LB0003-G3	Battery Cover	1
16	LB0013	Battery Retaining Strap	1
17	ZT0010	Grommet	1